WebOS quick install

1. Go to the main (start) screen on your Palm Pre or Pixi
2. Start typing "webos20090606" without the quotation marks.
3. Tap the Developer Mode icon and turn Developer Mode on.
4. Set Developer Mode to ON.
5. When asked, tap Reset The Device. Your phone will restart.
6. Connect the USB cable to your computer and select "Just Charge" when the phone prompts you.